

POUND-IN LANDSCAPE EDGING



INSTALLATION INSTRUCTIONS

1



Clear the installation area of grass, loose soil, mulch, and debris. Create a score along the installation area with a spade or shovel.

2



Hammer the top of the edging so that the edging height above ground is 2 inches or less. Stake along the installation as needed to secure the design.

3



Backfill and tamp soil against the edging on both sides to secure the wall. Spread mulch or other ground cover up to the wall of the edging.

HELPFUL TIPS & INFORMATION

Preparation:

Allow the edging to relax in the sun to allow for thermal expansion. Installing the edging when expanded and pulling tightly can reduce undesirable waves in straight installations.

Enough anchoring stakes are included to accommodate a typical installation. Certain conditions and landscape designs will require additional stakes, which are available in stores and online.

If you have rocky soil, dampen the installation area with a water hose. This will loosen pebbles and rocks. If you hit a rock with the edging or a stake, reposition slightly to avoid the underground obstacle.

Cutting & Connecting:

Edging can be cut with a fine-toothed saw or heavy-duty snips. When using the scalloped style of edging, cut between scallops for best results.

To connect two pieces of edging, overlap the edging ends at least $\frac{1}{2}$ to 1 inch. Place the stake hook over the top of both edging pieces and gently tap the stake head until the edging is secure in the ground.

Always use proper safety precautions when cutting and staking edging. Protective eyewear and gloves are recommended during installation.